



Reflow Profile Troubleshooting Guide

1. Incomplete Thermal Equilibrium of Board/Component
2. Component Shock & solder splatter
3. Insufficient Solvent Evaporation
4. The Depletion of Flux Activators, Oxidation
5. Incomplete wetting, incomplete joint fillet, void formation
6. Component and/or Board Damage

